

Superior and large capacity dust extractor

The ATTIX 44 dust extractor series sets a new standard for design and feature level of the Nilfisk wet & dry vacuum portfolio. With innovative filtration system, improved performance and robust design, this range represents a superior solution for professional customers looking for a safe and reliable machine with large capacity. ATTIX 44 comes with more suction power, sealed dust system, automatic filter cleaning and several other user benefits - designed to meet the tough requirements in building & constructions and other industries when picking up bigger amounts of dust.

ATTIX 44 offers a remarkable productivity thanks to the automatic filter cleaning system InfiniClean™. The InfiniClean™ system ensures continuously cleaning of the filter during operation using a reversed air-flow pulse, keeping suction performance on a high level. The downtime is reduced significantly, as the container can be filled up without filter maintenance – even in the most demanding fine dust applications. Also the washable PTFE long-life filter minimizes maintenance and reduces the overall service cost.




Easy handling and user-friendliness - also when it comes to transportation from one working site to another - are other valuable features for the ATTIX 44 dust extractor. All models offer flexible storage solutions for tools and accessories, so everything you need is at hand.



Picture shown may not represent model quoted









- InfiniClean™ - Automatic filter cleaning system with minimized performance loss
- PTFE long-life filter with non-stick membrane and minimum 99.9% filtration efficiency
- Dust class L certification
- Unique dual filter solution available with HEPA filtration.
- 42 liter container with steel castors and robust bumper.
- MultiFit accessory system for the ultimate in task flexibility
- Flexible rubber straps, tool box storage and optional trolley handle for convenient storage and transport
- Optional motor cooling filter, exhaust air collector and Long-Life filter bag

● Standard equipment

Included accessories		Ref. no.	Min. required	ATTIX 44-2L IC 220-240V 50/60HZ EU	ATTIX 44-21 IC 120V 50/60HZ US	ATTIX 44-21 IC HEPA 120V 50/60HZ US
Filter						
	FLAT FILTER PTFE M-CLASS 1 PCS	107413540	0			●
System 32 Hose Vacuum Cleaner						
	HOSE Ø32X4000MM AS RED	107413543	0			●
	HOSE SLEEVE Ø32 PVC	14682	0			●
System 36 Hose Vacuum Cleaner						



## Superior and large capacity dust extractor

Included accessories		Ref. no.	Min. required	ATTIX 44-2L IC 220-240V 50/60HZ EU	ATTIX 44-21 IC 120V 50/60HZ US	ATTIX 44-21 IC HEPA 120V 50/60HZ US
	HOSE Ø36X4000 MM AS RED	107413544	0			
	UNIV HOSE WITH HAND TUBE D32X3500 PE	107409976	0	•		
<b>System 36 Tube</b>						
	CURVED HAND TUBE Ø36MM SS	46691	0			•
	EXTENSION TUBE Ø36 2X505MM SS	107408074	0			•
	TOOL ADAPTER D27 QUICKSYSTEM	302000535	0			•
<b>System 36 Vac Floor Nozzle</b>						
	FLOOR NOZZLE D36X400MM W/D	302003666	0			•
<b>System 36 Crevice/Cone Nozzle</b>						
	CREVICE NOZZLE D36X200	29541	0			•
<b>Other</b>						
	FLEXIBLE STRAP SET 2 PCS	107413553	0	•	•	

Model	ATTIX 44-2L IC 220-240V 50/60HZ EU	ATTIX 44-21 IC 120V 50/60HZ US	ATTIX 44-21 IC HEPA 120V 50/60HZ US
Ref. no.	107412106	107412125	107412178

## PRODUCT FEATURES

Softstart	•	•	•
Anti-static system	•	•	•
Motor speed control	•	•	•



## Superior and large capacity dust extractor



Model	ATTIX 44-2L IC 220-240V 50/60HZ EU	ATTIX 44-21 IC 120V 50/60HZ US	ATTIX 44-21 IC HEPA 120V 50/60HZ US
Ref. no.	107412106	107412125	107412178

## PRODUCT FEATURES

Automatic on/off-elec. tools	•	•	•
M-class hazardous dust approval			
Storage of accessories	•	•	•
Extra socket for tool	•	•	•
Hose and cable holder	•	•	•
L-class hazardous dust approval	•		
Disposal bag 1 pcs	•	•	•
Fleece filter bag 1 pcs			
Tool box storage system			












Technical specifications	ATTIX 44-2L IC 220-240V 50/60HZ EU	ATTIX 44-21 IC 120V 50/60HZ US	ATTIX 44-21 IC HEPA 120V 50/60HZ US
Power pmax (W)	1400		
Power piec (W)	1200	890	890
Mains connection (V/~ /HZ/A)	230/1/50-60/16	120/1/50-60/15	120/1/50-60/15
Air flow rate (L/M)	4500	4260	4260
Vacuum (MBAR/KPA)	250/25	230/23	230/23
Working sound level (DB-A)	60	60	60
EI cable (M)	7.5	7.5	7.5
Container volume (L-MAX)	42	42	42
Filter cleaning system	InfiniClean	InfiniClean	InfiniClean
Main filter type	PTFE	PTFE	PTFE
Length x width x height (MM)	565x385x605	565x385x605	565x385x605
Weight (KG)	16	16	16

• Standard equipment, ○ Supplementary accessories, □ Mountable equipment












Accessories	Ref. no.	Min. required	ATTIX 44-2L IC 220-240V 50/60HZ EU	ATTIX 44-21 IC 120V 50/60HZ US	ATTIX 44-21 IC HEPA 120V 50/60HZ US
<b>System 36 Crevice/Cone Nozzle</b>					
 CREVICE NOZZLE D36X200	29541	0			•
 CREVICE NOZZLE Ø36X300 PP	6084	0			○






## Superior and large capacity dust extractor

Accessories		Ref. no.	Min. required	ATTIX 44-2L IC 220-240V 50/60HZ EU	ATTIX 44-21 IC 120V 50/60HZ US	ATTIX 44-21 IC HEPA 120V 50/60HZ US
	CREVICE NOZZLE Ø 36X15X920 ST/CR	17836	0			○
	DIA. TUBE NOZZLE Ø36X190 MM GREY RUBBER	5067	0			○
	FLAT NOZZLE Ø36MM RUBBER	40456	0			○
<b>System 36 Brush/Universal Nozzle</b>						
	BRUSH NOZZLE Ø36X70	5146	0			○
	BRUSH NOZZLE Ø36X230	6086	0			○
	OVAL BRUSH NOZZLE Ø36MM	40455	0			○
	RADIATOR BRUSH NOZZLE Ø36X420	5144	0			○
	SUCTION BRUSH D36 BLACK	302002509	0			○
	UNIV NOZZLE Ø36X150 ALU	5145	0			○
	UNIVERSAL NOZZLE D36X115	14295	0			○
<b>System 36 Vac Floor Nozzle</b>						
	COMBI NOZZLE Ø36X260MM	302002365	0	○	○	











## Superior and large capacity dust extractor

Accessories		Ref. no.	Min. required	ATTIX 44-2L IC 220-240V 50/60HZ EU	ATTIX 44-21 IC 120V 50/60HZ US	ATTIX 44-21 IC HEPA 120V 50/60HZ US
	FLOOR NOZZLE COMBI Ø36X270MM	107417892	0	○		
	FLOOR NOZZLE D36X300MM W/D KIT	107402706	0	○	○	
	FLOOR NOZZLE D36X400MM W/D	302003666	0			●
	FLOOR NOZZLE Ø36X300MM	302002331	0			○
	FLOOR NOZZLE Ø36X330 ALU	5147	0			○
	FLOOR NOZZLE Ø36X400 SPECIAL WET/DRY	5149	0			○
	NOZZLE ALU. 450XØ36MM DRY	15348	0			○
	NOZZLE ALU. 450XØ36MM WET	15349	0			○
	WATER SUCTION NOZZLE Ø36X300	7270	0			○
<b>System 50 Tube</b>						
	ADAPTER Ø 58-36 mmx124 mm	40452	0	○	○	
	CURVED ALU EXT.TUBE D50X1000	15335	0			○











## Superior and large capacity dust extractor

Accessories		Ref. no.	Min. required	ATTIX 44-2L IC 220-240V 50/60HZ EU	ATTIX 44-21 IC 120V 50/60HZ US	ATTIX 44-21 IC HEPA 120V 50/60HZ US
	SUCTION TUBE 2PCS Ø50 525MM PVC	5152	0	○	○	
<b>System 50 Brush/Universal Nozzle</b>						
	COARSE DIRT NOZZLE Ø50X175 PP	5153	0			○
	COARSE DIRT NOZZLE Ø50X200MM ALU	41100	0			○
	ROUND BRUSH NOZZLE INNER DIA Ø58MM	40458	0			○
<b>System 38 Hose Vacuum Cleaner</b>						
	HOSE HEAT RES. 36X4000 FOR	6070	0	○	○	
	UNIV HOSE Ø36-38X4000MM EVA	15365	0			○
<b>Tools</b>						
	CHIP SET D50MM	61681	0			○
	INDUSTR. FLOOR SET Ø36MM 4-PCS	63214	0			○
	INDUSTR. FLOOR SET Ø50MM 6-PCS	63216	0			○
	INDUSTRIAL SET 38	302002881	0	○	○	
	PIPE CLEANING SET Ø 38MM 4-PCS	63215	0			○

## Superior and large capacity dust extractor












Accessories		Ref. no.	Min. required	ATTIX 44-2L IC 220-240V 50/60HZ EU	ATTIX 44-21 IC 120V 50/60HZ US	ATTIX 44-21 IC HEPA 120V 50/60HZ US
	STANDARD VAC SET Ø50MM 3-PCS	6085	0			○
	WORKSHOP SET Ø36MM 6-PCS	302000927	0	○	○	
<b>System 27 Brush/Universal Nozzle</b>						
	CURRY COMB Ø27MM	6092	0	○	○	
<b>System 50 Crevice/Cone Nozzle</b>						
	CREVICE NOZZLE Ø58,6X370 PE	7102	0			○
	DIAGONAL TUBE NOZZLE Ø50 RUBBER	7868	0			○
<b>System 38 Crevice/Cone Nozzle</b>						
	PIPE CLEAN NOZZLE Ø38 R120-200MM	8054	0	○	○	
<b>System 27 Hose Vacuum Cleaner</b>						
	HOSE D27X3500 AS WITH TOOL ADAPTER LDPE	107406091	0			○
	TOOL ADAPTER D27/36-24 AS	107404520	0	○	○	
	UNIV HOSE Ø27X3500 WITH TOOL ADAPTER EVA	14289	0			○
<b>System 32 Hose Vacuum Cleaner</b>						
	AS HOSED32X4000MM WITH TOOL	30657	0			○
	HOSE Ø32X4000MM AS RED	107413543	0			●

## Superior and large capacity dust extractor











Accessories		Ref. no.	Min. required	ATTIX 44-2L IC 220-240V 50/60HZ EU	ATTIX 44-21 IC 120V 50/60HZ US	ATTIX 44-21 IC HEPA 120V 50/60HZ US
	HOSE SLEEVE Ø32 PVC	14682	0			•
<b>System 50 Hose Vacuum Cleaner</b>						
	CHIPS HOSE Ø50X4000MM	15182	0			○
	UNI. HOSE Ø50X4000MM EVA/ABS	15358	0			○
<b>System 38 Tube</b>						
	CURVED HAND TUBE D38 MM SS	302002889	0	○	○	
	EXTEN TUBE THERMAL INSULATE Ø38X2500MM	15340	0	○	○	
	EXTENSION TUBES R38 2X500 KIT	107402474	0	○	○	
<b>System 50 Vac Floor Nozzle</b>						
	FLOOR NOZZLE ALU. 500XØ50MM DRY	15343	0			○
<b>System 36 Hose Vacuum Cleaner</b>						
	HOSE Ø36X4000 MM AS RED	107413544	0	○	○	
	UNI. HOSE Ø36X3000MM EVA	15805	0			○
	UNI. HOSE Ø36X3000MM W COUPLING EVA	46948	0			○





## Superior and large capacity dust extractor

Accessories		Ref. no.	Min. required	ATTIX 44-2L IC 220-240V 50/60HZ EU	ATTIX 44-21 IC 120V 50/60HZ US	ATTIX 44-21 IC HEPA 120V 50/60HZ US
	UNIV HOSE WITH HAND TUBE D32X3500 PE	107409976	0	•	○	
<b>System 36 Tube</b>						
	ADAPTER TUBE STRAIGHT AS Ø36MM	29457	0			○
	CURVED HAND TUBE Ø36MM SS	46691	0			•
	EXTENSION TUBE D36 2X500MM ALU	107400032	0			○
	EXTENSION TUBE D36 2X505MM ST/CR	302000529	0			○
	EXTENSION TUBE D36 2X515MM PLASTIC	40696	0			○
	EXTENSION TUBE D36 3X350 MM SS	107416995	0			○
	EXTENSION TUBE Ø36 2X505MM SS	107408074	0			•
	TELESCOPIC TUBE Ø36X550-970 SS	47109	0			○
	TOOL ADAPTER D27 QUICKSYSTEM	302000535	0			•
	TOOL ADAPTER D27/35/38	60916	0			○

## Superior and large capacity dust extractor

	Accessories	Ref. no.	Min. required	ATTIX 44-2L IC 220-240V 50/60HZ EU	ATTIX 44-21 IC 120V 50/60HZ US	ATTIX 44-21 IC HEPA 120V 50/60HZ US
	TOOL ADAPTER WITH SUCTION REGULATION D32	107409977	0			○
<b>Filter</b>						
	FILTER ELEMENT Ø140X75 H-CLASS/HEPA	107413555	0			○
	FLAT FILTER PTFE M-CLASS 1 PCS	107413540	0			●
	HEPA FILTER COVER KIT	107413542	0			○
<b>Special Filter</b>						
	MOTOR COOLING AIR FILTER PET 1 PCS	107413541	0			○
<b>Filter Bag</b>						
	FLEECE FILTER BAG 5 PCS ATTIX 33/44	107419593	0	○	○	
	LONG LIFE FILTER BAG 1 PCS ATTIX 33/44	107413556	0			○
<b>Other</b>						
	ADAPTER PLATE KIT	107413551	0			○
	FLEXIBLE STRAP SET 2 PCS	107413553	0	●	●	
	STORAGE L-BOXX KIT W. DUSTBAGS	107413554	0			○

Superior and large capacity dust extractor

Accessories		Ref. no.	Min. required	ATTIX 44-2L IC 220-240V 50/60HZ EU	ATTIX 44-21 IC 120V 50/60HZ US	ATTIX 44-21 IC HEPA 120V 50/60HZ US
	TROLLEY HANDLE KIT	107413552	0			○
Disposal Bag						
	DISPOSAL BAG ATTIX 33/44 5 PCS	107417821	0			○
Exhaust Air Collector						
	EXHAUST AIR ADAPTER KIT	107417865	0			○

